




DisneyBand+




The DisneyBand+ is two different sized bands in one and can be sized to fit most Guests.



For smaller sizes, push the inner band away from the outer band by using a thumb or index finger. Peel the DisneyBand+ swiftly for best results.



Make sure the DisneyBand+ is fitted securely against your wrist facing up.



The **icon** is removable with the help of a small screwdriver under adult supervision. Be sure not to over-tighten the screws.

NOTE

Changes or modifications not expressly approved by Disney could void user's authority to operate equipment.

FCC COMPLIANCE INFORMATION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



Designed in the USA